

**RANGER**

## SCALE CABIN

**Product introduction:**

1. Complete fibre material, strike-tolerable.
2. Baking varnish manufactured with fine appearance.
3. Transparent windshield, authentic/veritable and beautiful.
4. Crane attached, probability and practical which makes the takeoff and decline more stable.

**Specification:**

产品型号: EK4-0059 (grey)

推荐适用机型:

ESKY EK1H-E013/EK1H-E014/EK1H-E015

Length: 680mm

high: 117mm

wide: 125mm

**产品介绍:**

1. 全玻璃纤维材质，耐冲击。
2. 烤漆制作，外观精美。
3. 全透明挡风窗，真实，美观。
4. 特配升降架，像真实用，让起飞下降更加稳定。

**产品规格:**

产品型号: EK4-0059 (灰色)

推荐适用机型:

ESKY EK1H-E013/EK1H-E014/EK1H-E015

机身长: 680mm

机身高: 117mm

机身宽: 125mm

**包装散开图 Packing**

包装盒: 724\*130\*130mm

package: 724\*130\*130mm

EK4-E0059

**打开包装 Open the package**

Let's beginning! ▶▶▶



将整机试飞调试好  
Adjust the helicopter well and  
text the fly.



将平尾，垂尾，滑撬拆下。  
Disassemble the tail paddle, and  
vertical fin and landing skit.



将尾箱拆下，拉杆取下。  
Disassemble the tail box and  
remove the push-rod.



将主机架放进机壳  
Put the main body into the scale  
cabin.



将尾箱装上并套上拉杆  
Assemble the tail box and fit on  
the push-rod.



用螺丝把滑撬与主机架固定好  
(螺丝: 2\*25mm 4个)  
Fix the landing skit and the main  
frame with the screws.  
(Screw: 2\*25mm 4PCS)



把尾罩用螺丝固定好  
(自攻螺丝: 1.4\*5mm 3个)  
Fix the tail cover with screws.  
(Self-tapping screw: 1.4\*5mm 3PCS)



把机头罩用螺丝固定好  
(自攻螺丝: 1.4\*5mm 8个)  
Fix the canopy with the screws.  
(Self-tapping screw: 1.4\*5mm 8PCS)



把座仓装上  
(自攻螺丝: 1.4\*5mm 4个)  
Assemble the cabin. (Self-tapping  
screw: 1.4\*5mm 4PCS)



用AB胶把平衡尾粘好  
Stick up the tail paddle with AB  
glue.



把接收机天线绑在平尾上  
Tie up the receiver antenna on  
the tail paddle.